



Part-list	ES	EN	Prod.
1	A	GRUPO A	GROUP A
2	B	GRUPO B	GROUP B
3	C	GRUPO C	GROUP C

Prod.	ES	EN	From serial num.
24994	RUBIMIX-16 ERGOMAX 230V 50/60HZ	RUBIMIX-16 ERGOMAX 230V 50/60HZ	-
24995	RUBIMIX-16 ERGOMAX 110V 50/60HZ UK	RUBIMIX-16 ERGOMAX 110V 50/60HZ UK	-
24996	RUBIMIX-16 ERGOMAX 230V 50/60HZ UK	RUBIMIX-16 ERGOMAX 230V 50/60HZ UK	-
24997	RUBIMIX-16 ERGOMAX 120V 50/60HZ USA	RUBIMIX-16 ERGOMAX 120V 50/60HZ USA	-
24998	RUBIMIX-16 ERGOMAX 230V 50/60HZ C/MALETA	RUBIMIX-16 ERGOMAX 230V 50/60HZ W/CASE	-
24999	RUBIMIX-16 ERGOMAX 230V 50/60HZ UK C/MAL	RUBIMIX-16 ERGOMAX 230V 50/60HZ UK W/CAS	-


Queda reservado el derecho de introducir cualquier modificacion técnica sin previo aviso
 We reserve the right to introduce any technical modification without previous notice



Part-list	ES	EN	Prod.	
1	24345	12 TORN ST3,9X14	SCREW ST3,9X14	
2	24346	1 TAPA MOTOR TRASERA RUBIMIX-16 ERGOMAX	REAR COVER RUBIMIX-16 ERGOMAX	
3	24347	1 TAPA VENTILACION RMIX-16 ERGOMAX POS.3	AIR GUIDE COVER RUBIMIX-16 ERGOMAX POS.3	
4	24348	1 MANGO PLAST.SUPERIOR RUBIMIX-16 ERGOMAX	TOP PLASTIC HANDLE RUBIMIX-16 ERGOMAX	
5	24349	1 ABRAZADERA POS.5 RUBIMIX-16 ERGOMAX	CLAMP BOARD RUBIMIX-16 ERGOMAX	
6	24350	1 TUERCA M8 RUBIMIX-16 ERGOMAX	NUT M8 RUBIMIX-16 ERGOMAX	
7	24351	1 POMO ABRAZADERA RUBIMIX-16 ERGOMAX	CLAMP KNOB RUBIMIX-16 ERGOMAX	
8	24352	2 FIJACION ABRAZADERA RUBIMIX-16 ERGOMAX	CLAMP MAT RUBIMIX-16 ERGOMAX	
9	24353	1 MANGO PLAST.INFERIOR RUBIMIX-16 ERGOMAX	UNDER PLASTIC HANDLE RUBIMIX-16 ERGOMAX	
10	24354	17 TORN ST3,9X16	SCREW ST3,9X16	
11	24355	2 JGO TAPA ESCOBILLA RUBIMIX-16 ERGOMAX 2U	BRUSHER COVER RUBIMIX-16 ERGOMAX	
12	24407	2 ESCOBILLA RUBIMIX-16 ERGOMAX 110V	CARBON BRUSHER RUBIMIX-16 ERGOMAX 110V	24995, 24997
12	24356	2 ESCOBILLA RUBIMIX-16 ERGOMAX 230V	CARBON BRUSHER RUBIMIX-16 ERGOMAX 230V	24994, 24996, 24998, 24999
13	24357	2 JGO PORTAESCOBILLA RUBIMIX-16 ERGOMAX 2U	BRUSHER HOLDER RUBIMIX-16 ERGOMAX	
14	24358	1 CARCASA MOTOR RUBIMIX-16 ERGOMAX	MOTOR HOUSE RUBIMIX-16 ERGOMAX	
37	24412	1 CABLE ENCHUFE RMIX-16 ERGOMAX 110V UK	POWER CORD RUBIMIX-16 ERGOMAX 110V UK	24995
37	24381	1 CABLE ENCHUFE RMIX-16 ERGOMAX 230V VDE	POWER CORD RUBIMIX-16 ERGOMAX 230V VDE	24994, 24998
37	24410	1 CABLE ENCHUFE RMIX-16 ERGOMAX 110V USA	POWER CORD RUBIMIX-16 ERGOMAX 110V USA	24997
37	24411	1 CABLE ENCHUFE RMIX-16 ERGOMAX 230V UK	POWER CORD RUBIMIX-16 ERGOMAX 230V UK	24996, 24999
38	24382	1 FUNDA CABLE RUBIMIX-16 ERGOMAX	CORD SHEATH RUBIMIX-16 ERGOMAX	
39	24383	1 JUNTA CABLE ENCHUFE RUBIMIX-16 ERGOMAX	CORD BOARD RUBIMIX-16 ERGOMAX	
40	24384	1 INTERRUPTOR 230V RUBIMIX-16 ERGOMAX	SWITCH CONTROL 230V RUBIMIX-16 ERGOMAX	24994, 24996, 24998, 24999
40	24529	1 INTERRUPTOR 110V RUBIMIX-16 ERGOMAX	SWITCH CONTROL 110V RUBIMIX-16 ERGOMAX	24995, 24997
41	24385	1 CONDENSADOR RUBIMIX-16 ERGOMAX	CAPACITOR RUBIMIX-16 ERGOMAX	
42	24386	1 MUELLE CABLE RUBIMIX-16 ERGOMAX	SPRING WIRE RUBIMIX-16 ERGOMAX	
43	24387	1 FUNDA CABLE PEQUEÑA RUBIMIX-16 ERGOMAX	SMALL CORD SHEATH RUBIMIX-16 ERGOMAX	



Part-list	ES	EN	Prod.
1	24345 12	TORN ST3,9X14	SCREW ST3,9X14
15	24359 1	ESTATOR RUBIMIX-16 ERGOMAX 230V	STATOR RUBIMIX-16 ERGOMAX 230V
15	24408 1	ESTATOR RUBIMIX-16 ERGOMAX 110V	STATOR RUBIMIX-16 ERGOMAX 110V
16	24360 2	TORN ST4,8X60	SCREW ST4,8X60
17	24361 1	ANILLO VENTILACION MOTOR RMIX-16 ERGOMAX	MOTOR WIND RING RUBIMIX-16 ERGOMAX
18	24362 1	SOPORTE RODAMIENTO RUBIMIX-16 ERGOMAX	BEARING HOLDER RUBIMIX-16 ERGOMAX
19	24363 1	RODAMIENTO 608 RUBIMIX-16 ERGOMAX	BEARING 608 RUBIMIX-16 ERGOMAX
20	24364 1	ROTOR RUBIMIX-16 ERGOMAX 230V	ROTOR RUBIMIX-16 ERGOMAX 230V
20	24409 1	ROTOR RUBIMIX-16 ERGOMAX 110V	ROTOR RUBIMIX-16 ERGOMAX 110V
21	24365 1	RODAMIENTO 6001 RUBIMIX-16 ERGOMAX	BEARING 6001 RUBIMIX-16 ERGOMAX
22	24366 1	MUELLE POS.22 RUBIMIX-16 ERGOMAX	SPRING POS.22 RUBIMIX-16 ERGOMAX
44	24388 1	TAPA VENTILACION RMIX-16 ERGOMAX POS.44	WIND COVER RUBMIX-16 ERGOMAX POS.44
45	24389 3	TORN M4X6	SCREW M4X6
46	24390 1	TAPA MOTOR RUBIMIX-16 ERGOMAX	MOTOR COVER RUBMIX-16 ERGOMAX
47	24391 2	VARILLA ACEITE RUBIMIX-16 ERGOMAX	OIL BAR RUBMIX-16 ERGOMAX
48	24392 1	ARAND TAPA ACEITE RUBIMIX-16 ERGOMAX	OIL COVER WASHER RUBMIX-16 ERGOMAX
49	24393 1	TAPA ACEITE RUBIMIX-16 ERGOMAX	OIL COVER RUBMIX-16 ERGOMAX
50	24394 4	ARAND 3 RUBIMIX-16 ERGOMAX	WASHER FLAT 3.0 RUBMIX-16 ERGOMAX
51	24395 4	ARAND GROWER 3 RUBIMIX-16 ERGOMAX	SPRING WASHER 3.0 RUBMIX-16 ERGOMAX
52	19466 4	TORN M3X10	SCREW M3X10
53	24397 1	RODAMIENTO HK1010 RUBIMIX-16 ERGOMAX	BEARING HK1010 RUBMIX-16 ERGOMAX
54	19487 1	ANILLO ELASTICO 15MM	CIRCLIP 15MM
55	24399 1	ENGRANAJE GRANDE RUBIMIX-16 ERGOMAX	BIG GEAR RUBMIX-16 ERGOMAX
56	19489 1	ANILLO ELASTICO 17MM	CIRCLIP 17MM
57	19490 1	ANILLO ELASTICO 35MM	CIRCLIP 35MM
59	24403 1	RODAMIENTO 6003 RUBIMIX-16 ERGOMAX	BEARING 6003 RUBMIX-16 ERGOMAX
65	24562 2	CONEXION ESTATOR-ESCOB.RMIX-16 ERGOMAX	STATOR-BRUSH CONNECT.RMIX-16 ERGOMAX



Part-list	ES	EN	Prod.
23	24367 1	TORN M4X14	SCREW M4X14
24	24368 1	REGULADOR VELOCIDAD RUBIMIX-16 ERGOMAX	KNOB SPEED SHIFT RUBIMIX-16 ERGOMAX
25	24369 2	BOLA ACERO 4.0 RUBIMIX-16 ERGOMAX	STEEL BALL 4.0 RUBIMIX-16 ERGOMAX
26	24370 2	MUELLE POS.26 RUBIMIX-16 ERGOMAX	SPRING POS.26 RUBIMIX-16 ERGOMAX
27	24371 1	ANILLO ELASTICO 28MM	CIRCLIP 28MM
28	24372 1	EJE REGULADOR VELOCIDAD RMIX-16 ERGOMAX	SPEED SHIFT POLE RUBIMIX-16 ERGOMAX
29	24373 1	TAPA ACEITE 21X26X5 RUBIMIX-16 ERGOMAX	FRAME OIL COVER 21X26X5 RMIX-16 ERGOMAX
30	19422 4	TORN ST4,8X55	SCREW ST4,8X55
31	24375 1	CAJA ENGRANAJES RUBIMIX-16 ERGOMAX	GEAR BOX RUBIMIX-16 ERGOMAX
32	24376 1	PRISIONERO 4H 8X8	PIN4H 8X8
33	24377 3	RODAMIENTO 628/8 RUBIMIX-16 ERGOMAX	BEARING 628/8 RUBIMIX-16 ERGOMAX
34	24378 1	ENGRANAJE INICIAL CL.III RMIX-16 ERGOMAX	INITIATIVE GEAR CL.III RMIX-16 ERGOMAX
35	24379 1	ENGRANAJE TRANSM.CL.III RMIX-16 ERGOMAX	DRIVEN GEAR CL.III RMIX-16 ERGOMAX
36	24380 1	ENGRANAJE TRANSM.CL.II RMIX-16 ERGOMAX	DRIVEN GEAR CL.II RMIX-16 ERGOMAX
58	19491 1	ANILLO ELASTICO 10MM	CIRCLIP 10MM
60	24404 1	ENGRANAJE TRANSM.CL.I RMIX-16 ERGOMAX	DRIVEN GEAR CL.I RMIX-16 ERGOMAX
61	24405 1	EJE ENGRANAJE CL.II RMIX-16 ERGOMAX	GEAR SHAFT CL.II RMIX-16 ERGOMAX
62	24406 1	PASADOR RUBIMIX-16 ERGOMAX	SPINDLE RUBIMIX-16 ERGOMAX
63	25702 1	MALETA RMIX-16 ERGOMAX	CASE RMIX-16 ERGOMAX
64	25603 1	RODAMIENTO 688-Z 8X16X5	BEARING 688-Z 8X16X5
66	25742 1	ASA MALETA RMIX-16 ERGOMAX	CASE HANDLE RMIX-16 ERGOMAX